

From \$CS107E/src/interrupts_asm.s

```
_vectors:  
    ldr pc, abort_addr  
    ldr pc, abort_addr  
    ldr pc, abort_addr  
    ldr pc, abort_addr  
    ldr pc, abort_addr  
    ldr pc, abort_addr  
    ldr pc, interrupt_addr  
    ldr pc, abort_addr  
  
    abort_addr:      .word abort_asm  
    interrupt_addr:  .word interrupt_asm  
  
_vectors_end:
```

Symbols `_vectors` and `_vectors_end` mark region to be copied

From \$CS107E/src/interrupts.c

```
void interrupts_init(void)  
{  
    unsigned int *dst = _RPI_INTERRUPT_VECTOR_BASE;  
    unsigned int *src = &_amp;vectors;  
    unsigned int n = &_amp;vectors_end - &_amp;vectors;  
  
    for (int i = 0; i < n; i++) {  
        dst[i] = src[i];  
    }  
  
}
```

From \$CS107E/src/interrupts_asm.s

```
interrupt_asm:
1  mov    sp, #0x8000    @ init IRQ stack
2  sub    lr, lr, #4     @ compute resume addr (in lr)
3  push  {r0-r12, lr}   @ save all registers
4  mov    r0, lr        @ pass resume addr as arg
5  bl    interrupt_dispatch @ call C function
6  ldm    sp!, {r0-r12, pc}^ @ restore saved registers
                               pc = resume addr (from lr)
                               ^ change mode & restore cpsr
```

Line 1: assign banked sp (shared fp left as-is). backtrace from perspective of interrupt handler will cross from irq to svc stack (unintentional, but sort of neat)

Line 2: banked lr holds pc at time of interrupt (+8 because of pipeline)

Line 3: save all non-banked registers for simplicity and safety (could save just callee-owned registers since C function should obey conventions, but...)

Line 5: call C function interrupt_dispatch (unsigned int arg)

Line 6: consider why all of these actions must happen as one unit